# MC9100 Configuration Guide







CONFIGURATION OPTIONS:	MC91xx	OPTION	DESCRIPTION
Radio Option	MC919x-xxxxxxxxx	9	WLAN 802.11 a/b/g
Form Factor	MC9190-Gxxxxxxxxxx	G	Gun
Data Capture options (Scanner)	MC9190-GAxxxxxxxx	А	SE960 1D Standard range laser
	MC9190-GJxxxxxxxx	J	SE1524ER Lorax Long Range Laser
	MC9190-G3xxxxxxxxx	3	SE4500 Blockbuster Imager
	MC9190-G5xxxxxxxxx	5	SE4500 Blockbuster Imager with DPM
	MC9190-G8xxxxxxxxx	8	SE4500 Blockbuster DL Imager for Driver License
	MC9190-G9xxxxxxxxx	9	SE4600 Long Range Imager
WAN Carrier options	MC9190-Gx0xxxxxxxx	0	None
Display	MC9190-Gxx <mark>S</mark> xxxxxxx	S	Color 3.7" Diagonal (640 x 480 pixels) w/ Touch
Memory options	MC9190-GxxxWxxxxxx	W	256 MB RAM / 1 GB Flash
Product Feature: User Input/Keyboard	MC9190-GxxxxAxxxxx	А	28 Key Numeric Keypad
	MC9190-GxxxxExxxxx	E	53 Key Alpha-Numeric Keypad
	MC9190-GxxxxFxxxxx	F	43 Key Numeric Keypad
	MC9190-GxxxxGxxxxx	G	53 key VT Emulator Keypad
	MC9190-GxxxxHxxxxx	Н	53 key 3270 Emulator Keypad
	MC9190-GxxxxJxxxxx	J	53 key 5250 Emulator Keypad
<b>Operating System Options</b>	MC9190-GxxxxxQxxxx	Q	Windows Mobile 6.5
	MC9190-GxxxxxYxxxx	Y	Windows Compact Embedded 6.0
Additional Features	MC9190-GxxxxxA6xx	A6	Audio, Voice, Bluetooth
	MC9190-GxxxxxC6xx	C6	Condensation Resistant with Audio, Voice, Bluetooth
Country or Custom Code	MC9190-GxxxxxxxWR	WR	Worldwide ROHS
	MC9190-GxxxxxxxJP	JP	Japan
	MC9190-GxxxxxxxTN	TN	Tunisia



## **MC9100 Data Capture Methods**

#### **Scan Engines**

MC9190-GA	SE961 1D Standard range laser
MC9190-GJ	SE1524ER Lorax long range laser
MC9190-G3	SE4500 Blockbuster imager
MC9190-G5	SE4500 Blockbuster imager with DPM
MC9190-G8	SE4500 Blockbuster DL imager for driver license
MC9190-G8	SE4600 Long range imager



MC9190-GA 1D Standard Range Laser

MC9190-GJ Lorax Long Range Laser





MC9190-G3 MC9190-G5 MC9190-G8 Blockbuster Imager



## **MC9100 Keypad Options**

#### 28 Key Numeric Telephony

Large numeric keys Alpha character by SMS system

## Spare keypad part number: KYPD-MC9XMR000-01R



#### 43 Key Shifted Alpha

Calculator style numeric 12 direct function keys

## Spare keypad part number: KYPD-MC9XMT000-01R



#### 53 Key Alpha-Numeric

Full alpha-numeric keypad 10 shifted function keys

## Spare keypad part number: KYPD-MC9XMS000-01R





## **MC9100 Keypad Options**

#### 3270 Emulator Keypad

Full alpha-numeric 20 shifted function keys


## Spare keypad part number: KYPD-MC9XMV000-01R



#### 5250 Emulator Keypad

Full alpha-numeric 20 shifted function keys


## Spare keypad part number: KYPD-MC9XMW000-01R



#### VT Emulator Keypad

Full alpha-numeric 20 shifted function keys

## Spare keypad part number: **KYPD-MC9XMU000-01R**



The emulator keypads are only used when the MC9190-G is running the respective emulation software, otherwise the functions are same as 53- key keypad.



## **MC9100 Operating Systems**



Microsoft Windows Embedded Handheld 6.5 Classic Edition

Microsoft Windows Embedded Compact 6.0



#### **Operating System Configurations**

**Microsoft Windows** Embedded handheld 6.5 classic edition

Microsoft Windows Embedded compact 6.0



## **MC9100 Additional Features**





Voice



Bluetooth

**Condensation Resistant** 



### **Additional Features**

C6 Audio, Voice, Bluetooth, Condensation Resistant





Single Slot Cradle:

CRD9000-1001SR Single slot USB / RS232 Cradle, w/spare battery charging

#### Single Slot Cradle Kits:

CRD9000-111SES (INTERNATIONAL)

Includes: Single Slot Cradle CRD9000-1001SR and Power Supply PWRS-14000-148R. (Must purchase country specific 3 wire AC Cord separately)

Includes: Single Slot Cradle CRD9000-CRD9000-110SES 1001SR, Power Supply PWRS-14000-148R (US) and US AC Cord 23844-00-00R.

> The single slot cradle can charge a MC9190-G/MC92N0 gun, charges a spare battery and has USB master and slave connections.

**Additional Accessories for** Single Slot Cradle



25-64396-01R USB Cable for the cradle to the host system



25-63852-01R

Provides serial communication between the single slot cradle and a host computer.



#### PWRS-14000-148R

Power supply for single slot cradle: 100-240 VAC, 12VDC, 4.16A



#### 23844-00-00R

US AC line cord, 7.5 feet long, grounded, three wire for power supplies.

#### 25-63856-01R

Modem adapter cable used to connect the MDM9000-100R to the single slot cradle





CRD9101-4001CR 4 Slot Charge Only Cradle CRD9000-4001ER 4 Slot Ethernet Cradle

#### 4 Slot Cradle Kits:

CRD9101-411CES (INTERNATIONAL)

**CRD9000-411EES** 

(INTERNATIONAL)

Includes: 4 Slot Charge Only Cradle CRD9000-4001ER, Power Supply PWRS-14000-241R and DC Cord 50-16002-029R. Order country specific 3 wire AC Cord separately

**Includes: 4 Slot Ethernet** Cradle CRD9000-4001ER, Power Supply PWRS-14000-241R and DC Cord 50-16002-029R. Order country specific 3 wire AC Cord separately

CRD9000-410EES Includes:4 Slot Ethernet Cradle CRD9000-4001ER, Power Supply PWRS-14000-241R, DC Cord 50-16002-029R and US AC Cord 23844-00-00R.

#### Additional Accessories for 4-slot Cradles



PWRS-14000-241R

Power supply for 4 slot cradles:90-264 VAC, 12VDC, 9A



#### 50-16002-029R

DC cable provides power from the power supply to 4 slot charge only and Ethernet cradles



#### 23844-00-00R

US AC line cord, 7.5 feet long, grounded, three wire for power supplies.



#### **Wall Mounting Bracket**



#### KT-61498-01R

Wall mounting bracket, order one for a single slot cradle on one for the 4 slot battery charger, order two for 4 slot cradles. Must purchase the cradle bracket separately to install the cradle on the wall mount bracket.

#### **Cradle Bracket**



#### KT-61499-01R

Cradle Bracket, order one for a single slot cradle and one for the 4 slot battery charger, order two for 4 Slot Cradles. Attaches to the bottom of the cradle and is required to install the cradle on the wall mounting bracket.





#### Forklift Cradle:

#### FLC9000-1001R

Provides a secure mounting solution, equipped with rugged RS232 and USB ports capable of powering and communicating with tethered devices.

The forklift cradle allows USB and RS232 connectivity between a docked MC9190-G/MC92N0-G and external devices such as scanners or printer (additional cables required)

#### Forklift Cradle Kits:

KT-FLC9000-LV

Includes Fork Lift Cradle (FLC9000-1001R), Low Voltage Power Converter (PWRS-14000-252R) and Power Cable (25-103873-01R)

**KT-FLC9000-HV** Includes Fork Lift Cradle (FLC9000-1001R), High Voltage Power Converter (PWRS-14000-251R), Power Cable (25-103872-01R)

Must purchase separately:

Specific power converter : PWRS-14000-252R for

- low voltage or PWRS-14000-251R for high voltage
- Power input cable :25-103872-01R

#### Additional Accessories for Forklift Cradle



#### PWRS-14000-251R

Fork Lift High Voltage Power Converter from 18-75VDC to 12VDC



#### PWRS-14000-252R

Fork Lift Low Voltage Power Converter from 9-30VDC to 12VDC



#### **25-103872-01R** Forklift power input cable





#### 25-71917-02R

RS232 Cable, coiled 9' extended, rugged amphenol connector.

#### 25-71918-01R

USB Cable, coiled 9' extended, rugged amphenol connector



## **Step 2: Choose battery / battery charging accessories**



2200 mAh Battery

#### **KT-21-61261-01** Spare Lithium Ion battery, 2200 mAh

Pack of 10 spare batteries is also available: (BTRY-MC90GKAB0E-10)

#### **Spare Battery Charging Options:**



**CRD9000-1001SR** Single Slot Serial / USB Cable with spare battery charging



**SAC9000-4000R** 4-slot battery charger, charges four spare batteries.

#### **Accessories for 4-slot Battery Charger:**

**25-72614-01R** DC Line Cord for 4-Slot Battery Charger

**PWRS-14000-242R** Power supply for 4-Slot Battery Charger



**23844-00-00R** US AC line cord, 7.5 feet long, grounded, three wire for power supplies.

#### **4-slot Battery Charger Kits:**


SAC9000-400CES

US kit. Includes: 4-slot battery charger SAC9000-4000R, power supply PWRS-14000-242R, DC line cord 25-72614-01R and US AC line cord 23844-00-00R.

**KIT-SAC9000-4001ES** International kit. Includes 4-slot battery charger SAC9000-4000R, power supply PWRS-14000-242R and DC line cord 25-72614-01R, must purchase country specific AC line cord separately.



## **Step 3: Choose charging cables/adapters**



for adapter module

ADP9000-120R (5VDC - 350mA) for use with Apriva BT200 Reader



## **Step 4: Choose carrying accessories**

Bt200



58-40000-007R

Universal shoulder strap for holster.



## 11-08062-02R



Universal belt for fabric holster.



## **Step 5: Choose other accessories**

# AudioRCH51Rugged wired headset designed for<br/>use in nearly any environment25-124387-02RRCH51 headset adapter cable to<br/>standard 3-pole 2.5mm barrel jack.



#### **Belt Clip Kit**

KT-70147-01R

Belt clip kit is designed to hold the mobile computers firmly in place while on the move.



## **Step 5: Choose other accessories**

#### **Plastic Screen Guards**

KT-151827-03R	Pack of 3 screen guards
KT-151827-500R	Pack of 500 screen guards
KIT-MC9X- SCRP1L-50	Laminate exit window overlay for use in food processing environment- Pack of 50

66

**KT-151827-03R** Plastic Screen Guards





KT-68144-10R Replacement Grey Stylus

#### **Hand straps**

**KT-66447-03R** Replacement hand straps - Pack of 3

#### **Stylus Kits**

KT-68144-10R	Replacement grey stylus - Pack of 10
KT-68144-50R	Replacement grey stylus - Pack of 50

KT-81680-50R Replacement Grey Stylus with tether



## **Step 5: Choose other accessories**



Bluetooth Headsets for WBA/VDP use case only



#### **Bluetooth Headsets** (for MC9200 only)

B250XT+VXi Corp Bluetooth Wireless HeadsetExpressway IIVXi Corp Bluetooth Wireless Headset

#### **Forklift Ballistic Holster**

Y6911DWSP Ballistic Nylon Holster for Forklift, Vehicle or Wall Mounting

#### Card Reader (For MC9100 only)

#### 1139-01-SO-MC9X00-CAC

TSL Common Access Card (CAC) Reader capable of reading Common Access Cards (CAC) as well as Smart Cards compliant with ISO7816-1,2,3,4.

**B250-XT+** Bluetooth Headset for MC9200 **Expressway II** Bluetooth Headset for MC9200



1139-01-SO-MC9X00-CAC TSL Common Access Card reader for MC9100